



LeatherZ Interior Chrome Items

E-Brake Button

To remove your stock E-brake button, simply untwist it. You will have to unthread the stock button for a long time (several minutes), trust me, it will come off. Installation of your new chrome button is the same as removal. Simply twist it on.

Headlight Pull

To remove your stock headlight pull, use a very small screw driver to pry it off. Be very careful that you pull the screw driver and not pivot it as you will probably damage piece the pull is going on. The headlight pulls have 2 areas where you can fit a screwdriver in. You may need to rotate the pull to find these. Installation is as simple as pushing the new pull on. There are three female grooves on the back side of the headlight pull, these fit on male counterparts on the housing for the pull.

Door Lock Pins

Before beginning, roll your windows down so you do not risk damage to the glass. In order to remove the stock lock pins, use a pair of needle nose or other small pliers and simply pull them straight up. Once removed you will see wire the pins sit on. To install the new pins, open one of the doors. With the door open, pull the interior door handle, this will prevent the wire from being able to push down as you the car will not let you lock the door. Simply push the new chrome lock pin onto the wire. Repeat on the other side and you are finished.

Customer Satisfaction

If you like my work, please drop me a line and let me know. Tell other Z3 and M owners. If you are not happy with my work, let me know. Let me make it right for you. -- Andy Maddux